
Table of Contents

(Revision 4, July 2007)

Preface (Rev 4, July 2007)		
Contact ACES Systems		1
Warranty		3
Calibration and Certification		4
<hr/>		
1 Introduction (Rev 2, Feb 2005)		
1.1	Notes, Cautions, and Warnings	1-2
1.2	Conventions	1-2
<hr/>		
2 Analyzer Description (Rev 3, April 2006)		
2.1	Keypad	2-2
2.2	Screen	2-5
2.3	Input and Output Ports	2-5
2.3.1	CHANNEL Ports	2-6
2.3.2	TACH Ports	2-6
2.3.3	BATT CHG Port	2-6
2.3.4	AUX/COMM Port	2-6
2.3.5	STROBE Port	2-7
2.4	Standard Equipment	2-7
2.4.1	Battery	2-7
2.4.1.1	Lead Acid Batteries	2-7
2.4.1.2	Nickel Metal Hydride Batteries	2-7
2.4.2	Battery Charger	2-8
2.4.2.1	Lead Acid Battery Chargers	2-8
2.4.2.2	Nickel Metal Hydride Battery Chargers	2-8
2.4.2.3	Charging the Battery	2-9
2.4.3	Communications/Printer Cable	2-10
2.4.4	Carrying Case	2-10
2.4.5	User Manual	2-11
2.5	Optional Equipment	2-11
2.5.1	Propeller Balancing Kit	2-11
2.5.1.1	Manual, <i>ACES Systems Guide to Propeller Balancing</i>	2-11
2.5.1.2	991D-1 Accelerometer	2-12
2.5.1.3	991D-1 Sensor Cable	2-12
2.5.1.4	Phototach	2-12
2.5.1.5	Tachometer Sensor Cable	2-13
2.5.1.6	Propeller Protractor	2-14

2.5.1.6.1	Using the Propeller Protractor	2-14
2.5.1.7	Case Bolt Adapter Set	2-15
2.5.1.8	Tackle Box	2-15
2.5.1.9	Right-Angle Sensor Mount	2-16
2.5.1.10	Gram Scale	2-16
2.5.1.11	Video Tape, <i>Using the Model 2020 ProBalancer Analyzer</i>	2-16
2.5.1.12	Reflective Tape	2-16
2.5.1.13	ACES Systems Balance Placard	2-17

3 Using the Model 2020 ProBalancer Analyzer (Rev 2, April 2006)

3.1	Entering Data	3-1
3.1.1	Using the Keys	3-1
3.1.2	Filling in Fields	3-2
3.2	Loading a Setup	3-2
3.3	Main Menu	3-3
3.3.1	Adjusting the Screen Contrast	3-3

4 Propeller Balance (Rev 4, July 2007)

4.1	Start Job	4-2
4.1.1	Prop Balance Setup	4-3
4.1.1.1	Prop Balance Setup Without EPS Upgrade	4-4
4.1.1.1.1	Edit ICF	4-6
4.1.1.1.2	Sensor Setup	4-7
4.1.1.2	Propeller Balance Setup With EPS Upgrade	4-7
4.1.1.2.1	Edit ICF	4-10
4.1.1.2.2	Sensor Setup	4-10
4.1.1.2.3	Prop Hole Layout Setup	4-11
4.1.2	Customer Information	4-13
4.1.3	Engine Information	4-14
4.1.4	Prop Balance Equipment Setup	4-14
4.1.4.1	Tachometer Setup	4-14
4.1.5	Start Aircraft	4-15
4.1.6	Acquiring Data	4-16
4.1.7	Review Job	4-17
4.1.8	Balance Solution	4-18
4.1.8.1	Balance Solution Without EPS Upgrade	4-18
4.1.8.1.1	Set Split Weights	4-19
4.1.8.1.2	Record Split Weights	4-20
4.1.8.2	Balance Solution With EPS Upgrade	4-22
4.1.9	Vibration Summary	4-23
4.2	Resume Job	4-25
4.3	Manage Jobs	4-26
4.3.1	Review	4-26
4.3.2	Print	4-26
4.3.3	Print All	4-26
4.3.4	Delete	4-27
4.3.5	Delete All	4-27
4.4	Manage Setups	4-27
4.4.1	Edit	4-27
4.4.2	New	4-28
4.4.3	Print	4-28
4.4.4	Print All	4-28

4.4.5	Delete	4-28
4.5	Weight Calculator	4-29

5 Main Rotor Track & Balance (Rev 3, July 2007)

5.1	Start Job	5-2
5.1.1	Main Rotor Setup	5-2
5.1.2	Customer Information	5-5
5.1.3	Tracking Selections	5-5
5.1.4	Main Rotor Equipment Setup	5-6
5.1.4.1	Optical Tachometer Setup	5-6
5.1.5	Start Aircraft	5-7
5.1.5.1	Select Aircraft Condition	5-8
5.1.5.2	Acquiring Vibration Data	5-9
5.1.5.3	Review Data	5-9
5.1.5.4	Review Prior Runs	5-10
5.2	Resume Job	5-11
5.3	Manage Jobs	5-11
5.3.1	Review	5-12
5.3.2	Print	5-12
5.3.3	Print All	5-12
5.3.4	Delete	5-12
5.3.5	Delete All	5-13
5.4	Manage Setups	5-13
5.4.1	Edit	5-13
5.4.2	New	5-13
5.4.3	Print	5-14
5.4.4	Print All	5-14
5.4.5	Delete	5-14

6 Tail Rotor Balance (Rev 2, Feb 2005)

6.1	Start Job	6-1
6.1.1	Tail Rotor Setup	6-2
6.1.2	Customer Information	6-4
6.1.3	Tail Rotor Setup	6-5
6.1.3.1	Vibration Sensor Installation	6-5
6.1.3.2	Phototach Installation and Test	6-5
6.1.4	Start Aircraft	6-6
6.1.4.1	Run 1, Acquiring Vibration Data	6-7
6.1.4.2	Review Prior Run(s) Data	6-7
6.2	Resume Job	6-8
6.3	Manage Jobs	6-8
6.3.1	Review	6-9
6.3.2	Print	6-9
6.3.3	Print All	6-9
6.3.4	Delete	6-9
6.3.5	Delete All	6-10
6.4	Manage Setups	6-10
6.4.1	Edit	6-11
6.4.2	New	6-11
6.4.3	Print	6-11
6.4.4	Print All	6-11
6.4.5	Delete	6-11

7 Vibration Spectrum Surveys (Rev 3, July 2007)		
7.1	Start Job	7-2
7.1.1	Spectra Setup	7-3
7.1.1.1	Edit Conditions	7-6
7.1.2	Customer Information	7-7
7.1.3	Engine Information	7-7
7.1.4	Select Aircraft Condition	7-8
7.1.5	Start Component	7-9
7.1.6	Collecting Data	7-9
7.1.7	Storing Data	7-12
7.2	Resume Job	7-14
7.3	Manage Jobs	7-14
7.3.1	Review	7-15
7.3.2	Print	7-15
7.3.3	Print All	7-15
7.3.4	Delete	7-16
7.3.5	Delete All	7-16
7.4	Manage Setups	7-16
7.4.1	Edit	7-17
7.4.2	New	7-17
7.4.3	Print	7-17
7.4.4	Print All	7-17
7.4.5	Delete	7-18
8 Monitor Spectrum (Rev 3, July 2007)		
9 Monitor IPS and Clock (Rev 3, July 2007)		
10 Monitor Magnitude and Phase (Rev 3, July 2007)		
11 Monitor Overall Vibration (Rev 3, July 2007)		
12 Check Track (Rev 3, April 2006)		
13 Transfer Data with PC and Miscellaneous (Rev 2, Feb 2005)		
13.1	Transfer Data with PC	13-2
13.2	Miscellaneous Items	13-3
13.2.1	Setup Printers	13-3
13.2.2	Setup Sensors	13-4
13.2.2.1	Add or Edit Sensors	13-5
13.2.2.2	Print, Print All, or Delete Sensor	13-7
13.2.3	Set Date and Time	13-8
13.2.4	Check Battery	13-9
13.2.5	Analyzer Information	13-10
13.2.5.1	Entering a License Number for EPS	13-12
13.2.6	Database Information	13-13

14 Printing (Rev 2, Feb 2005)		
14.1	Supported Printers	14-2
14.2	Printer Data Setup	14-3
14.3	Printer Equipment Setup	14-5
14.3.1	Print to a Serial Printer with DB25M Connector	14-5
14.3.1.1	Equipment Required	14-5
14.3.1.2	Equipment Setup	14-5
14.3.2	Print to Serial Printer with DB9M Connector	14-6
14.3.2.1	Equipment Required	14-6
14.3.2.2	Equipment Setup	14-6
14.3.3	Print to Parallel Printer with Converter	14-7
14.3.3.1	Equipment Required	14-7
14.3.3.2	Equipment Setup	14-8
14.3.4	Print to Parallel Printer with Powered Converter	14-9
14.3.4.1	Equipment Required	14-9
14.3.4.2	Equipment Setup	14-9
14.4	Print	14-10
15 Equipment and Accessory Setup and Troubleshooting (Rev 2, Feb 2005)		
15.1	Battery Charger	15-1
15.2	Cables	15-1
15.3	LASETACH®	15-2
15.4	Phototach	15-2
15.5	Propeller Protractor	15-2
15.6	Reflective Tape (3M Tape, Model 7610)	15-2
15.6.1	Reflective Tape Width Requirements	15-3
15.7	Vibration Sensor	15-4
15.8	Optical Tachometer	15-4
15.9	Reinitializing the Analyzer	15-4
16 Reading Spectrum and Scales (Rev 2, Feb 2005)		
16.1	Reading the X and Y Plotted Vibration Spectrum	16-1
16.2	Reading the Converging Vibration Indicator and Scale	16-2
17 Specifications, Model 2020 ProBalancer Analyzer (Rev 3, April 2006)		